








Operating instructions
CUP HEATER

GB




WHK-001





1.1 Introduction

We're very pleased that you have decided to purchase one of our high-quality products. The cup heater is designed to keep cups and mugs warm. You are advised to read these instructions carefully so that you can make full and safe use of the apparatus.



Keep the fold out sheet opened while reading the instructions.


Contents

Page

1.1 INTRODUCTION	1
1.2 MODELS AND TYPES	1
1.3 WARNINGS AND SAFETY MEASURES	2
1.4 A QUICK GLANCE AT THE APPARATUS	2
1.5 PLACING THE APPARATUS	2
1.6 INSTRUCTIONS FOR USE.....	3
1.7 CLEANING, MAINTENANCE AND REPAIRS	3

1.2 Models and types

These operating instructions apply to the cup heater WHK-001.



WHK-001



1.3 Warnings and safety measures

The following warnings and precautions must be observed to safeguard the safe use of the heating plate:

WARNINGS

- △ Do not spray the device so that it becomes wet and do not submerge it in water.
- △ Make sure that the mains lead never comes into contact with the cup warming plates.
- △ The machine must always be connected to the electrical mains so it is easy to unplug from the mains.
- △ The manufacturer accepts no liability for damage caused by installation, use or maintenance of the equipment other than specified in these instructions.
- △ During use some parts of the equipment become very hot.

PRECAUTIONS

- If the apparatus is not to be used for a long period, it is recommended to disconnect it from the mains.
- Have all repair work carried out by a specialist service engineer.
- In the case of repair and/or maintenance activities in which the machine must be opened, all wires including the earth wire must be disconnected from the mains
- The equipment should be earthed.
- Always use approved materials and components during installation.
- During the installation activities, always observe local regulations and standards.

1.4 A quick glance at the apparatus

The principal parts of the apparatus can be seen on the fold-out flap. Keep this sheet opened while reading the instructions.

1. *On/off switch lower cup warming plate*
2. *Lower cup warming plate*
3. *On/off switch upper cup warming plate*
4. *Upper cup warming plate*

TECHNICAL DATA

See the type plate on the machine for data relating to power, model and type number, etc. We recommend that you record this data in the drawing of the type plate in the back of this instruction manual.


DIMENSION SKETCH

See the dimension sketch on the fold out sheet for the measurements.

1.5 Placing the apparatus

1. Place the apparatus in the working area
2. Check that it is secure and horizontal
3. Check that there is a free mains socket close by and place the plug in the apparatus and the socket.

The apparatus is now ready for use.

WARNING 
Ensure that the mains lead never comes into contact with the cup warming plates.



1.6 Instructions for use

1. Turn the cup warming plates on by setting the ON/OFF switch (1 and 3) to ON. The light in the switches will go on.
2. Place cups and beakers on the cup warming plates.
3. Turn off the cup warming plates when the cups and beakers are going to be removed for a long period of time.
4. To do this, turn switch 1 and 3 to OFF. The light in the switches will go out.

WARNING



Some parts of the equipment will become very hot during use.

1.7 Cleaning, maintenance and repairs

The best way of cleaning the apparatus is with a damp cloth, if necessary with a detergent that is non-abrasive and/or corrosive.

For maintenance and repair work please contact your supplier or one of the service points.



PRECAUTION



If the apparatus has to be opened, e.g. for repair, first remove the plug from the mains socket.



WHK-001
(max. 16 A)



Model :

Type : 8

Vlgnr. :VHH

CE01

.....V 50/60HZ.....W





BRAVILOR[®]
BONAMAT[®]

COFFEE BREWING MACHINES

© 04-2001

700.403.320 A